

# Installation example for *revos*

## Multipole hoods for cable-to-cable couplings

Size	Thread	Hood Pos. 1	Hood Pos. 2	Hood Pos. 3	Bottom-base Pos. 4	Bottom-base Pos. 5	Hood Pos. 6
6	M20	99.741.3329.7	70.352.0636.4	70.350.0636.4	99.700.3329.7	70.320.0628.9	99.731.3329.7
	M25	99.742.3329.7	70.354.0636.4	70.353.0636.4	–	–	99.732.3329.7
10	M20	99.743.3329.7	70.352.1036.4	70.350.1036.4	99.706.3329.7	70.320.1028.9	99.733.3329.7
	M25	99.744.3329.7	70.354.1036.4	70.353.1036.4	–	–	99.734.3329.7
16	M25	99.745.3329.7	70.352.1636.4	70.350.1636.4	99.702.3329.7	70.320.1628.9	99.735.3329.7
	M32	99.746.3329.7	70.354.1636.4	70.353.1636.4	–	–	99.736.3329.7
24	M25	99.747.3329.7	70.352.2436.4	70.350.2436.4	99.704.3329.7	70.320.2428.9	99.737.3329.7
	M32	99.748.3329.7	–	–	–	–	99.738.3329.7
48	M32	70.372.4836.4	70.375.4836.4	70.350.4828.4	–	70.320.4828.9	–
	M40	70.374.4836.4	70.376.4836.4	–	–	–	–

