



Raspberry Pi Camera User Manual

CONTENTS

1.	Basic o	perations	2
2.	Camer	a module setup	2
	2.1.	CONNECTING THE CAMERA	2
	2.2.	ENABLING THE CAMERA	2
	2.3.	USING THE CAMERA	3
3.	Refere	nce	3

1. Basic operations

- 1) Please download Raspbian OS from http://www.raspberrypi.org/
- 2) Format your TF card with the SDFormatter.exe.

Notices: The capability of TF card in used here should be more than 4GB. In this operation, a TF card reader is also required, which has to be purchased separately.

 Start the Win32DiskImager.exe, and select the system image file copied into your PC, then, click the button Write to program the system image file.

Figure 1: Programming the system image file with Win32DiskImager.exe

😼 Win32 Disk Imager 📃 📼 💌
Image File Device
':/install/raspberrypi/2013-05-25-wheezy-raspbian.img 📄 [I:\] 🔻
Copy MD5 Hash: Progress
Version: 0.8 Cancel Read Write Exit Waiting for a task.

2. Camera module setup

2.1. CONNECTING THE CAMERA

The flex cable inserts into the connector situated between the Ethernet and HDMI ports, with the silver connectors facing the HDMI port. The flex cable connector should be opened by pulling the tabs on the top of the connector upwards then towards the Ethernet port. The flex cable should be inserted firmly into the connector, with care taken not to bend the flex at too acute an angle. The top part of the connector should then be pushed towards the HDMI connector and down, while the flex cable is held in place.

2.2. ENABLING THE CAMERA

- Update and upgrade Raspbian from the Terminal: apt-get update apt-get upgrade
- 2) Open the raspi-config tool from the Terminal: sudo raspi-config



3) Select Enable camera and hit Enter, then go to Finish and you'll be prompted to reboot.

Figure 2: Enable camera

info	Information about this tool
expand_rootfs	Expand root partition to fill SD card
overscan sonfiguna kauboard	Change overscan Set keyboard layout
change_pass	Change password for 'pi' user
change_locale	
change timezone	
Constant and the second s	Set hostnane
memory_split	Change memory split
overclock	Configure overclocking
ssh	Enable or disable ssh server
boot_behaviour	Start desktop on boot?
anera	Enable/Disable cammera addon support

2.3. USING THE CAMERA

Power up and take photos or shoot videos from the Terminal:

1) Taking photos:

raspistill -o image.jpg

2) Shooting videos:

raspivid -o video.h264 -t 10000

-t 10000 means the video last 10s, changeable.

3. Reference

Libraries for using the camera are available in:

Shell (Linux command line)

<u>Python</u>

More information:

https://www.raspberrypi.org/documentation/usage/camera/README.md https://www.raspberrypi.org/documentation/raspbian/applications/camera.md https://projects.raspberrypi.org/en/projects/getting-started-with-picamera